



TRU SHOT™ DISINFECTANT CLEANER

HOSPITAL CLEANER & DISINFECTANT RESTROOM CLEANER & DISINFECTANT

A fast and effective one-step spray and wipe virucide and disinfectant. Effective against a broad spectrum of bacteria, viruses, fungi and inhibits the growth of mold and mildew. For virtually any hard, non-porous surfaces such as countertops, stainless steel, sinks, toilets, tubs, doorknobs, floors, walls and garbage cans.

EFFECTIVE AGAINST

1 MINUTE CONTACT TIME:

Viruses:

HIV-1 (AIDS Virus)
Influenza Type A / Hong Kong (Influenza)

3 MINUTE CONTACT TIME:

Bacteria:

Pseudomonas aeruginosa (*Pseudomonas*)
Salmonella enterica (*Salmonella*)
Staphylococcus aureus (*Staph*)
Enterobacter aerogenes
Enterococcus faecalis (*Enterococcus*)
Enterococcus faecalis - Vancomycin resistant (VRE)
Escherichia coli (*E. coli*)
Escherichia coli O157:H7
ESBL Escherichia coli
(Extended spectrum beta-lactamase producing *E. coli*)
Klebsiella pneumoniae (*Klebsiella*)
Klebsiella pneumoniae, Carbapenem-resistant
Listeria monocytogenes
Serratia marcescens
Shigella dysenteriae (*Shigella*)
Shigella flexneri serotype 1B
Staphylococcus aureus
- Community Associated Methicillin Resistant
(CA-MRSA) (NRS384) (USA300)
Staphylococcus aureus - Methicillin-Resistant (MRSA)
Streptococcus pyogenes (*Strep*)

3 MINUTE CONTACT TIME Continued:

Viruses:

Hepatitis B Virus (HBV)
Hepatitis C Virus (HCV)
Herpes Simplex Virus Type 1
Herpes Simplex Virus Type 2
Human Coronavirus
Respiratory Syncytial Virus (RSV)
Rotavirus
Vaccinia (Pox Virus)

Fungi:

Candida albicans
Trichophyton mentagrophytes
(the Athlete's Foot Fungus)

5 MINUTE CONTACT TIME:

Virus:

Norwalk Virus (Norovirus)
(Feline Calicivirus)

10 MINUTE CONTACT TIME:

Bacteria:

Legionella pneumophila
Staphylococcus aureus
- Community Associated Methicillin Resistant
(CA-MRSA) (NRS123) (USA400)
Staphylococcus aureus - Multi-Drug Resistant

Viruses:

SARS Associated Coronavirus (SARS)
(cause of Severe Acute Respiratory Syndrome)





TRU SHOT™ DISINFECTANT CLEANER

TruShot™ CHEMISTRY CARTRIDGES

TruShot™ Cartridges require no user mixing. The color-coded and easy-to-read cartridges simplify compliance, reduce off-label usage, and deliver the comparable clean of up to 11 in-use quarts.

AVAILABLE PRODUCTS



RESTROOM CLEANER & DISINFECTANT

PRODUCT CODE	PACKAGE SIZE DESCRIPTION	IN-USE QUARTS
689945	6 x 10 oz. (296mL) TruShot™ Disinfectant Cleaner	10 oz. concentrate = Up to 11 in-use quarts



HOSPITAL CLEANER & DISINFECTANT

PRODUCT CODE	PACKAGE SIZE DESCRIPTION	IN-USE QUARTS
689950	6 x 10 oz. (296mL) TruShot™ Disinfectant Cleaner	10 oz. concentrate = Up to 11 in-use quarts



TRUSHOT™ DISINFECTANT CLEANER SPRAYER

PRODUCT CODE	PACKAGE SIZE DESCRIPTION	IN-USE QUARTS
690707	4 x 10 oz. TruShot™ Trigger	N/A

For effective product performance, use disinfectant cleaner chemistry cartridges only with a trigger marked FOR USE ONLY WITH THE TruShot™ DISINFECTANT CLEANER DILUTION SYSTEM

PRODUCT SPECIFICATIONS

DESCRIPTION	IN-USE	
PRODUCT CODE	689945	689950
SURFACES	Restrooms	Hospitals
COLOR	Colorless	Colorless
pH IN-USE	11	11
DENSITY	1.00 g/cm ³	1.00 g/cm ³
FRAGRANCE	Fresh	Odorless

INCOMPATIBLE MATERIALS

Do not mix with bleach or any other household cleaners.
Strong bases

SAFETY PRACTICES TO FOLLOW

It's good business practice to assure that your employees have read and understood the product labels and Safety Data Sheet before using this product. The label use directions and SDS contain important hazard warnings, precautionary statements and first aid procedures.

This information is available on-line at www.scjohnson-professional.com or by calling 800-294-3632. Wear personal protective equipment, chemical-resistant gloves and chemical splash goggles, when dispensing concentrates. Improper mixing or diluting of concentrate may damage surfaces and may result in physical harm to the user matching those of the concentrate.